



# Service Manual

## Air Conditioner



**Indoor Unit**  
**CS-S9NKUW-1**  
**CS-S12NKUW-1**  
**CS-S18NKU-1**  
**CS-S22NKU-1**

**Outdoor Unit**  
**CU-S9NKU-1**  
**CU-S12NKU-1**  
**CU-S18NKU-1**  
**CU-S22NKU-1**



Please file and use this manual together with the service manual for Model No. CU-2S18NBU, Order No. PHAAM1111121C1.

### **WARNING**

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

### **PRECAUTION OF LOW TEMPERATURE**



In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.

# TABLE OF CONTENTS


<b>1. Safety Precautions .....</b>	<b>3</b>	12.5 Compressor Overheating Prevention Control (For S18, S22NK only) .....	53
<b>2. Specification .....</b>	<b>5</b>	12.6 Low Pressure Protection Control (Gas Leakage Detection) .....	53
<b>3. Location of Controls and Components.....</b>	<b>9</b>	12.7 Low Frequency Protection Control 1 .....	53
3.1 Indoor Unit .....	9	12.8 Low Frequency Protection Control 2 .....	53
3.2 Outdoor Unit .....	9	12.9 Outdoor Air Temperature Control.....	54
3.3 Remote Control .....	9	12.10 Cooling Overload Control .....	54
<b>4. Dimensions .....</b>	<b>10</b>	12.11 Freeze Prevention Control .....	54
4.1 Indoor Unit .....	10	12.12 Freeze Prevention Control 2 .....	54
4.2 Outdoor Unit .....	12	12.13 Dew Prevention Control .....	54
<b>5. Refrigeration Cycle Diagram .....</b>	<b>13</b>	<b>13. Servicing Mode .....</b>	<b>55</b>
5.1 CS-S9NKUW-1 CU-S9NKU-1 CS-S12NKUW-1 CU-S12NKU-1 .....	13	13.1 Auto Off/On Button .....	55
5.2 CS-S18NKU-1 CU-S18NKU-1 CS-S22NKU-1 CU-S22NKU-1 .....	14	13.2 Remote Control Button .....	56
<b>6. Block Diagram .....</b>	<b>15</b>	<b>14. Troubleshooting Guide .....</b>	<b>57</b>
6.1 CS-S9NKUW-1 CU-S9NKU-1 CS-S12NKUW-1 CU-S12NKU-1 .....	15	14.1 Refrigeration Cycle System.....	57
6.2 CS-S18NKU-1 CU-S18NKU-1 CS-S22NKU-1 CU-S22NKU-1 .....	16	14.2 Breakdown Self Diagnosis Function.....	59
<b>7. Wiring Connection Diagram .....</b>	<b>17</b>	14.3 Error Code Table .....	60
7.1 Indoor Unit .....	17	14.4 Troubleshooting Flowchart .....	61
7.2 Outdoor Unit .....	19	<b>15. Disassembly and Assembly Instructions .....</b>	<b>84</b>
<b>8. Electronic Circuit Diagram .....</b>	<b>22</b>	15.1 Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures .....	84
8.1 Indoor Unit .....	22	<b>16. Technical Data .....</b>	<b>88</b>
8.2 Outdoor Unit .....	24	16.1 Operation Characteristics .....	88
<b>9. Printed Circuit Board .....</b>	<b>27</b>	<b>17. Exploded View and Replacement Parts List. 96</b>	
9.1 Indoor Unit .....	27	17.1 Indoor Unit .....	96
9.2 Outdoor Unit .....	29	17.2 Outdoor Unit .....	100
<b>10. Installation Instruction .....</b>	<b>31</b>		
10.1 S9NKUW-1 S12NKUW-1 .....	31		
10.2 S18NKU-1 S22NKU-1 .....	39		
<b>11. Operation Control.....</b>	<b>47</b>		
11.1 Basic Function .....	47		
11.2 Indoor Fan Motor Operation .....	48		
11.3 Outdoor Fan Motor Operation (For S9NK and S12NK).....	48		
11.4 Outdoor Fan Motor Operation (For S18NK and S22NK).....	48		
11.5 Airflow Direction.....	48		
11.6 Quiet Operation (Cooling Mode/Cooling Area of Dry Mode).....	49		
11.7 Powerful Mode Operation.....	50		
11.8 Timer Control.....	50		
11.9 Random Auto Restart Control .....	50		
11.10 Indication Panel.....	51		
<b>12. Protection Control.....</b>	<b>52</b>		
12.1 Restart Control (Time Delay Safety Control).. .....	52		
12.2 30 Seconds Forced Operation .....	52		
12.3 Total Running Current Control .....	52		
12.4 IPM (Power Transistor) Prevention Control.....	52		

# 1. Safety Precautions






- Read the following "SAFETY PRECAUTIONS" carefully before perform any servicing.
- Electrical work must be installed or serviced by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation or servicing due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.

 <b>WARNING</b>	This indication shows the possibility of causing death or serious injury.
 <b>CAUTION</b>	This indication shows the possibility of causing injury or damage to properties.


- The items to be followed are classified by the symbols:

	This symbol denotes item that is PROHIBITED from doing.
---	---







- Carry out test run to confirm that no abnormality occurs after the servicing. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

 <b>WARNING</b>	
1.	Do not modify the machine, part, material during repairing service.
2.	If wiring unit is supplied as repairing part, do not repair or connect the wire even only partial wire break. Exchange the whole wiring unit.
3.	Do not wrench the fasten terminal. Pull it out or insert it straightly.
4.	Engage authorized dealer or specialist for installation and servicing. If installation of servicing done by the user is defective, it will cause water leakage, electrical shock or fire.
5.	Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electric shock or fire.
6.	Use the attached accessories parts and specified parts for installation and servicing. Otherwise, it will cause the set to fall, water leakage, fire or electrical shock.
7.	Install at a strong and firm location which is able to withstand the set's weight. If the strength is not enough or installation is not properly done, the set will drop and cause injury.
8.	For electrical work, follow the local national wiring standard, regulation and the installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.
9.	This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case equipment breakdown or insulation breakdown.
10.	Do not use joint cable for indoor/outdoor connection cable. Use the specified indoor/outdoor connection cable, refer to installation instruction CONNECT THE CABLE TO THE INDOOR UNIT and connect tightly for indoor/outdoor connection. Clamp the cable so that no external force will be acted on the terminal. If connecting or fixing is not perfect, it will cause heat up or fire at the connection.
11.	Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause heat-up or fire at the connection point of terminal, fire or electrical shock.
12.	When install or relocate air conditioner, do not let any substance other than the specified refrigerant, eg. air etc. mix into refrigeration cycle (piping). (Mixing of air etc. will cause abnormal high pressure in refrigeration cycle and result in explosion, injury etc.).
13.	Do not install outdoor unit near handrail of veranda. When installing air-conditioner unit at veranda of high rise building, child may climb up to outdoor unit and cross over the handrail and causing accident.
14.	This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case equipment breakdown or insulation breakdown. 
15.	Keep away from small children, the thin film may cling to nose and mouth and prevent breathing. 
16.	Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire. 
17.	Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare may break and cause refrigerant gas leakage.
18.	For R410A models, when connecting the piping, do not use any existing (R22) pipes and flares nuts. Using such same may cause abnormally high pressure in the refrigeration cycle (piping), and possibly result in explosion and injury. In case of using existing (R22) pipes during installation of R410A models, must carry out pump down properly to collect back the refrigerant and oil before installation new unit. Thickness of copper pipes used with R410A must be more than 0.6mm. Never use copper pipes thinner than 0.6mm. It is desirable that the amount of residual oil is less than 40 mg/10m. 

### **WARNING**

19.	During installation, install the refrigerant piping properly before run the compressor. (Operation of compressor without fixing refrigeration piping and valves at opened condition will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc.).	
20.	During pump down operation, stop the compressor before remove the refrigeration piping. (Removal of refrigeration piping while compressor is operating and valves are opened condition will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc.).	
21.	After completion of installation or service, confirm there is no leakage of refrigerant gas. It may generate toxic gas when the refrigerant contacts with fire.	
22.	Ventilate if there is refrigerant gas leakage during operation. It may cause toxic gas when the refrigerant contacts with fire.	
23.	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury	
24.	Must not use other parts except original parts describe in catalog and manual.	
25.	Using of refrigerant other than the specified type may cause product damage, burst and injury etc.	

### **CAUTION**

1.	Do not install the unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	
2.	Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.	
3.	Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare may break and cause refrigerant gas leakage.	
4.	Do not touch outdoor unit air inlet and aluminium fin. It may cause injury.	
5.	Select an installation location which is easy for maintenance.	
6.	Pb free solder has a higher melting point than standard solder; typically the melting point is 50°F – 70°F (30°C – 40°C) higher. Please use a high temperature solder iron. In case of the soldering iron with temperature control, please set it to 700 ± 20°F (370 ± 10°C). Pb free solder will tend to splash when heated too high (about 1100°F / 600°C).	
7.	Power supply connection to the air conditioner. Connect the power supply cord of the air conditioner to the mains using one of the following methods. Power supply point shall be the place where there is ease for access for the power disconnection in case of emergency. In some countries, permanent connection of this room air conditioner to the power supply is prohibited. i. Power supply connection to the receptacle using a power plug. Use an approved 15/16A (1.0 ~ 1.75HP) or 16A (2.0HP) or 20A (2.5HP), power plug with earth pin for the connection to the socket. ii. Power supply connection to a circuit breaker for the permanent connection. Use an approved 16A (1.0 ~ 2.0HP) or 20A (2.5HP), circuit breaker for the permanent connection. It must be a double pole switch with a minimum 3.0 mm contact gap.	
8.	Do not release refrigerant during piping work for installation, servicing, reinstallation and during repairing a refrigerant parts. Take care of the liquid refrigerant, it may cause frostbite.	
9.	Installation or servicing work: It may need two people to carry out the installation or servicing work.	
10.	Do not install this appliance in a laundry room or other location where water may drip from the ceiling, etc.	
11.	Do not sit or step on the unit, you may fall down accidentally.	
12.	Do not touch the sharp aluminum fins , sharp parts may cause injury.	



## 2. Specification

Model			Indoor		CS-S9NKUW-1						CS-S12NKUW-1					
			Outdoor		CU-S9NKU-1						CU-S12NKU-1					
Performance Test Condition			ARI						ARI							
Power Supply		Phase, Hz	Single, 60						Single, 60							
		V	208			230			208			230				
			Min.	Mid.	Max.	Min.	Mid.	Max.	Min.	Mid.	Max.	Min.	Mid.	Max.		
Cooling	Capacity	kW	1.20	2.49	3.00	1.20	2.49	3.00	1.20	3.48	3.85	1.20	3.48	3.85		
		BTU/h	4100	8500	10200	4100	8500	10200	4100	11900	13100	4100	11900	13100		
	Running Current	A	-	3.7	-	-	3.3	-	-	5.1	-	-	4.6	-		
	Input Power	W	250	700	900	250	700	900	250	1.00k	1.15k	250	1.00k	1.15k		
	EER	W/W	4.80	3.56	3.33	4.80	3.56	3.33	4.80	3.48	3.35	4.80	3.48	3.35		
		Btu/hW	16.40	12.10	11.30	16.40	12.10	11.30	16.40	11.90	11.35	16.40	11.90	11.35		
	Power Factor	%	-	91	-	-	92	-	-	94	-	-	95	-		
	Indoor Noise (H / L / QLo)	dB-A	40 / 25 / 20			40 / 25 / 20			43 / 28 / 20			43 / 28 / 20				
		Power Level dB	56 / -			56 / -			59 / -			59 / -				
	Outdoor Noise (H / L / QLo)	dB-A	45 / - / -			47 / - / -			46 / - / -			48 / - / -				
		Power Level dB	60 / -			62 / -			61 / -			63 / -				
Max Current (A) / Max Input Power (W)			4.1 / 900						5.4 / 1.22k							
Starting Current (A)			3.7						5.1							
Min Circuit Ampacity			15.0						15.0							
Max. Overcurrent Protection			15.0						15.0							
Compressor	Type		Hermetic Motor (Rotary)						Hermetic Motor (Rotary)							
	Motor Type		Brushless (6 poles)						Brushless (6 poles)							
	Output Power	W	700						700							
Indoor Fan	Type		Cross-flow fan						Cross-flow fan							
	Material		ASG20K1						ASG20K1							
	Motor Type		Transistor (8 poles)						Transistor (8 poles)							
	Input Power		W						47.0 - 47.0							
	Output Power		W						30							
	Speed	QLo	rpm						610							
		Lo	rpm						710							
		Me	rpm						920							
Hi		rpm						1130								
SHi		rpm						1230								
Outdoor Fan	Type		Propeller						Propeller							
	Material		PP						PP							
	Motor Type		Induction (6 poles)						Induction (6 poles)							
	Input Power		W						-							
	Output Power		W						28							
	Speed	Hi	rpm						760 - 840							
Moisture Removal		L/h (Pt/h)	0.6 (1.3)						1.1 (2.3)							
Indoor Airflow	QLo	m³/min (ft³/min)	5.65 (199)						5.30 (187)							
	Lo	m³/min (ft³/min)	6.76 (239)						6.98 (246)							
	Me	m³/min (ft³/min)	9.08 (321)						9.49 (335)							
	Hi	m³/min (ft³/min)	11.4 (400)						12.0 (425)							
	SHi	m³/min (ft³/min)	12.51 (442)						13.36 (472)							
Outdoor Airflow	Hi	m³/min (ft³/min)	29.7 (1050)			31.0 (1095)			29.7 (1050)			31.0 (1095)				

Refrigeration Cycle	Control Device		Capillary Tube		Capillary Tube	
	Refrigerant Oil	cm <sup>3</sup>	RB68A or Freol Alpha68M (320)		RB68A or Freol Alpha68M (320)	
	Refrigerant Type	g (oz)	R410A, 965 (34.1)		R410A, 980 (34.6)	
Dimension	Height(I/D / O/D)	mm (inch)	290 (11-7/16) / 540 (21-9/32)		290 (11-7/16) / 540 (21-9/32)	
	Width (I/D / O/D)	mm (inch)	870 (34-9/32) / 780 (30-23/32)		870 (34-9/32) / 780 (30-23/32)	
	Depth (I/D / O/D)	mm (inch)	204 (8-1/16) / 289 (11-13/32)		204 (8-1/16) / 289 (11-13/32)	
Weight	Net (I/D / O/D)	kg (lb)	9 (20)	37 (82)	9 (20)	37 (82)
Piping	Pipe Diameter (Liquid / Gas)	mm (inch)	6.35 (1/4) / 9.52 (3/8)		6.35 (1/4) / 12.70 (1/2)	
	Standard length	m (ft)	7.5 (24.6)		7.5 (24.6)	
	Length range (min – max)	m (ft)	3 (9.8) ~ 15 (49.2)		3 (9.8) ~ 15 (49.2)	
	I/D & O/D Height different	m (ft)	5 (16.4)		5 (16.4)	
	Additional Gas Amount	g/m (oz/ft)	20 (0.2)		20 (0.2)	
	Length for Additional Gas	m (ft)	7.5 (24.6)		7.5 (24.6)	
Drain Hose	Inner Diameter	mm (inch)	16.7 (5/8)		16.7 (5/8)	
	Length	mm (inch)	650 (25-5/8)		650 (25-5/8)	
Indoor Heat Exchanger	Fin Material		Aluminium (Pre Coat)		Aluminium (Pre Coat)	
	Fin Type		Slit Fin		Slit Fin	
	Row x Stage x FPI		2 x 15 x 19		2 x 15 x 21	
	Size (W x H x L)	inch	(1) x (12-3/8) x (24)		(1) x (12-3/8) x (24)	
Outdoor Heat Exchanger	Fin Material		Aluminium (Blue coated)		Aluminium (Blue coated)	
	Fin Type		Corrugate Fin		Corrugate Fin	
	Row x Stage x FPI		2 x 24 x 17		2 x 24 x 17	
	Size (W x H x L)	inch	(1-3/8) x (19-7/8) x (28-1/8) (26-7/8)		(1-3/8) x (19-7/8) x (28-1/8) (26-7/8)	
Air Filter	Material		Polypropelene		Polypropelene	
	Type		One-touch		One-touch	
Power Supply			Outdoor		Outdoor	
Power Supply Cord		A	-		-	
Thermostat			-		-	
Protection Device			-		-	
			DRY BULB	WET BULB	DRY BULB	WET BULB
Indoor Operation Range		Maximum	89.6	73.4	89.6	73.4
		Minimum	60.8	51.8	60.8	51.8
Outdoor Operation Range		Maximum	109.4	78.8	109.4	78.8
		Minimum	60.8	51.8	60.8	51.8

1. Cooling capacities are based on indoor temperature of 80.6°F DRY BULB, 66°F WET BULB and outdoor air temperature of 95°F DRY BULB, 75.2°F WET BULB.


Model			Indoor		CS-S18NKU-1						CS-S22NKU-1						
			Outdoor		CU-S18NKU-1						CU-S22NKU-1						
Performance Test Condition					ARI						ARI						
Power Supply			Phase, Hz		Single, 60						Single, 60						
			V		208			230			208			230			
					Min.	Mid.	Max.	Min.	Mid.	Max.	Min.	Mid.	Max.	Min.	Mid.	Max.	
Cooling	Capacity		kW		1.30	5.01	5.80	1.30	5.01	5.80	1.30	6.18	6.85	1.30	6.18	6.85	
			BTU/h		4400	17100	19800	4400	17100	19800	4400	21000	23400	4400	21000	23400	
	Running Current		A		-	8.3	-	-	7.5	-	-	11.2	-	-	10.0	-	
	Input Power		W		250	1.65k	1.95k	250	1.65k	1.95k	250	2.25k	2.55k	250	2.25k	2.55k	
	EER		W/W		5.20	3.04	2.97	5.20	3.04	2.97	5.20	2.75	2.69	5.20	2.75	2.69	
			Btu/hW		17.60	10.35	10.15	17.60	10.35	10.15	17.60	9.30	9.15	17.60	9.30	9.15	
	Power Factor		%		-	96	-	-	96	-	-	97	-	-	98	-	
	Indoor Noise (H / L / QLo)		dB-A		47 / 39 / 36			47 / 39 / 36			47 / 39 / 36			47 / 39 / 36			
			Power Level dB		63 / -			63 / -			63 / -			63 / -			
	Outdoor Noise (H / L / QLo)		dB-A		47 / - / -			47 / - / -			50 / - / -			50 / - / -			
			Power Level dB		61 / -			61 / -			64 / -			64 / -			
Max Current (A) / Max Input Power (W)					9.0 / 1.99k						10.8 / 2.48k						
Starting Current (A)					8.3						11.2						
Min Circuit Ampacity					15.0						20.0						
Max. Overcurrent Protection					20.0						25.0						
Compressor		Type				Hermetic Motor (Scroll)						Hermetic Motor (Scroll)					
		Motor Type				Brushless (4 poles)						Brushless (4 poles)					
		Output Power		W		900						900					
Indoor Fan	Type				Cross-flow fan						Cross-flow fan						
	Material				ASG30K1						ASG30K1						
	Motor Type				Transistor (8 poles)						Transistor (8 poles)						
	Input Power		W		94.8 - 94.8						94.8 - 94.8						
	Output Power		W		30						30						
	Speed	QLo	rpm		990						990						
		Lo	rpm		1090						1090						
		Me	rpm		1270						1270						
		Hi	rpm		1460						1460						
SHi		rpm		1500						1500							
Outdoor Fan	Type				Propeller						Propeller						
	Material				PP						PP						
	Motor Type				Induction (8 poles)						Induction (8 poles)						
	Input Power		W		-						-						
	Output Power		W		38						38						
	Speed	Hi	rpm		500 - 550						550 - 600						
	Moisture Removal			L/h (Pt/h)		1.7 (3.6)						2.9 (6.1)					
Indoor Airflow	QLo	m³/min (ft³/min)		11.73 (414)						11.73 (414)							
	Lo	m³/min (ft³/min)		13.15 (464)						13.15 (464)							
	Me	m³/min (ft³/min)		15.70 (554)						15.70 (554)							
	Hi	m³/min (ft³/min)		18.4 (650)						18.4 (650)							
	SHi	m³/min (ft³/min)		18.97 (670)						18.97 (670)							
Outdoor Airflow	Hi	m³/min (ft³/min)		37.5 (1325)			41.6 (1470)			43.8 (1545)			47.5 (1675)				

Refrigeration Cycle	Control Device		Expansion Valve		Expansion Valve	
	Refrigerant Oil	cm <sup>3</sup>	RB68A or Freol Alpha68M (400)		RB68A or Freol Alpha68M (400)	
	Refrigerant Type	g (oz)	R410A, 1.18k (41.7)		R410A, 1.37k (48.4)	
Dimension	Height(I/D / O/D)	mm (inch)	290 (11-7/16) / 795 (31-5/16)		290 (11-7/16) / 795 (31-5/16)	
	Width (I/D / O/D)	mm (inch)	1070 (42-5/32) / 875 (34-15/32)		1070 (42-5/32) / 875 (34-15/32)	
	Depth (I/D / O/D)	mm (inch)	235 (9-9/32) / 320 (12-5/8)		235 (9-9/32) / 320 (12-5/8)	
Weight	Net (I/D / O/D)	kg (lb)	12 (26)	52 (115)	12 (26)	53 (117)
Piping	Pipe Diameter (Liquid / Gas)	mm (inch)	6.35 (1/4) / 12.70 (1/2)		6.35 (1/4) / 15.88 (5/8)	
	Standard length	m (ft)	5.0 (16.4)		5.0 (16.4)	
	Length range (min – max)	m (ft)	3 (9.8) ~ 20 (65.6)		3 (9.8) ~ 20 (65.6)	
	I/D & O/D Height different	m (ft)	15 (49.2)		15 (49.2)	
	Additional Gas Amount	g/m (oz/ft)	20 (0.2)		20 (0.2)	
	Length for Additional Gas	m (ft)	10 (32.8)		10 (32.8)	
Drain Hose	Inner Diameter	mm (inch)	16.7 (5/8)		16.7 (5/8)	
	Length	mm (inch)	650 (25-5/8)		650 (25-5/8)	
Indoor Heat Exchanger	Fin Material		Aluminium (Pre Coat)		Aluminium (Pre Coat)	
	Fin Type		Slit Fin		Slit Fin	
	Row x Stage x FPI		2 x 15 x 21		2 x 15 x 21	
	Size (W x H x L)	inch	(1) x (12-3/8) x (31-7/8)		(1) x (12-3/8) x (31-7/8)	
Outdoor Heat Exchanger	Fin Material		Aluminium (Blue coated)		Aluminium (Blue coated)	
	Fin Type		Corrugate Fin		Corrugate Fin	
	Row x Stage x FPI		2 x 36 x 19		2 x 36 x 18	
	Size (W x H x L)	inch	(1-3/8) x (29-3/4) x (24-3/8) (24-3/8)		(1-3/8) x (29-3/4) x (33) (31-7/8)	
Air Filter	Material		Polypropelene		Polypropelene	
	Type		One-touch		One-touch	
Power Supply			Outdoor		Outdoor	
Power Supply Cord		A	-		-	
Thermostat			-		-	
Protection Device			-		-	
			DRY BULB	WET BULB	DRY BULB	WET BULB
Indoor Operation Range		Maximum	89.6	73.4	89.6	73.4
		Minimum	60.8	51.8	60.8	51.8
Outdoor Operation Range		Maximum	109.4	78.8	109.4	78.8
		Minimum	60.8	51.8	60.8	51.8


- Cooling capacities are based on indoor temperature of 80.6°F DRY BULB, 66°F WET BULB and outdoor air temperature of 95°F DRY BULB, 75.2°F WET BULB.

## 3. Location of Controls and Components


### 3.1 Indoor Unit



### 3.2 Outdoor Unit




### 3.3 Remote Control




## 4. Dimensions

### 4.1 Indoor Unit

#### 4.1.1 CS-S9NKUW-1 CS-S12NKUW-1




## 4.1.2 CS-S18NKU-1 CS-S22NKU-1




## 4.2 Outdoor Unit

### 4.2.1 CU-S9NKU-1 CU-S12NKU-1




### 4.2.2 CU-S18NKU-1 CU-S22NKU-1






## 5. Refrigeration Cycle Diagram

### 5.1 CS-S9NKUW-1 CU-S9NKU-1 CS-S12NKUW-1 CU-S12NKU-1




5.2 CS-S18NKU-1 CU-S18NKU-1 CS-S22NKU-1 CU-S22NKU-1




## 6. Block Diagram

### 6.1 CS-S9NKUW-1 CU-S9NKU-1 CS-S12NKUW-1 CU-S12NKU-1




6.2 CS-S18NKU-1 CU-S18NKU-1 CS-S22NKU-1 CU-S22NKU-1




## 7. Wiring Connection Diagram

### 7.1 Indoor Unit

#### 7.1.1 CS-S9NKUW-1 CS-S12NKUW-1



7.1.2 CS-S18NKU-1 CS-S22NKU-1






7.2.2 CU-S18NKU-1

Resistance of Compressor Windings

CONNECTION	5CS130XAD04
U - V	0.902
U - W	0.903
V - W	0.900






## 7.2.3 CU-S22NKU-1

Resistance of Compressor Windings


CONNECTION	5CS130XAD04
U - V	0.902
U - W	0.903
V - W	0.900




8. Electronic Circuit Diagram

8.1 Indoor Unit

8.1.1 CS-S9NKUW-1 CS-S12NKUW-1






## 8.1.2 CS-S18NKU-1 CS-S22NKU-1




8.2 Outdoor Unit


8.2.1 CU-S9NKU-1 CU-S12NKU-1



## 8.2.2 CU-S18NKU-1



### 8.2.3 CU-S22NKU-1



### 9.1.1 Main Printed Circuit Board









## 9.2 Outdoor Unit

### 9.2.1 Main Printed Circuit Board

#### 9.2.1.1 CU-S9NKU-1 CU-S12NKU-1





# 10. Installation Instruction

## 10.1 S9NKUW-1 S12NKUW-1

### 10.1.1 Select the Best Location

#### 10.1.1.1 Indoor Unit

- Do not install the unit in excessive oil fume area such as kitchen, workshop and etc.
- There should not be any heat source or steam near the unit.
- There should not be any obstacles blocking the air circulation.
- A place where air circulation in the room is good.
- A place where drainage can be easily done.
- A place where noise prevention is taken into consideration.
- Do not install the unit near a door way.
- Ensure the spaces indicated by arrows from the wall, ceiling, fence or other obstacles.
- Recommended installation height for indoor unit shall be at least 8.2 ft.

#### 10.1.1.2 Outdoor Unit


- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- There should not be any animal or plant which could be affected by hot air discharged.
- Keep the spaces indicated by arrows from wall, ceiling, fence or other obstacles.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If piping length is over the [piping length for additional gas], additional refrigerant should be added as shown in the table.

Model	Capacity (Btu/h)	Piping size		Std. Length (ft)	Max. Elevation (ft)	Min. Piping Length (ft)	Max. Piping Length (ft)	Additional Refrigerant (oz/ft)	Piping Length for add. gas (ft)
		Gas	Liquid						
S9NKUW-1	8500	3/8"	1/4"	24.6	16.4	9.8	49.2	0.2	24.6
S12NKUW-1	11900	1/2"	1/4"	24.6	16.4	9.8	49.2	0.2	24.6

Example: For S9NKUW-1

If the unit is installed at 32.8 ft distance, the quantity of additional refrigerant should be 1.64 oz ....  $(32.8 - 24.6)$  ft x 0.2 oz/ft = 1.64 oz.


### 10.1.2 Indoor/Outdoor Unit Installation Diagram



### 10.1.3 Indoor Unit

#### 10.1.3.1 How to Fix Installation Plate

The mounting wall shall be strong and solid enough to prevent it from the vibration.



Model	Dimension					
	①	②	③	④	⑤	⑥
S9NКУW-1, S12NКУW-1	19 3/32"	3 7/32"	6 1/2"	6 7/32"	1 11/16"	3 3/4"

The centre of installation plate should be at more than ① at right and left of the wall.

The distance from installation plate edge to ceiling should more than ②.

From installation plate left edge to unit's left side is ③.

From installation plate right edge to unit's right side is ④.

- Ⓑ : For left side piping, piping connection for liquid should be about ⑤ from this line.  
 : For left side piping, piping connection for gas should be about ⑥ from this line.

- 1 Mount the installation plate on the wall with 5 screws or more (at least 5 screws).  
 (If mounting the unit on the concrete wall, consider using anchor bolts.)
  - Always mount the installation plate horizontally by aligning the marking-off line with the thread and using a level gauge.
- 2 Drill the piping plate hole with  $\varnothing 2 \frac{3}{4}$ " hole-core drill.
  - Line according to the left and right side of the installation plate. The meeting point of the extended line is the center of the hole. Another method is by putting measuring tape at position as shown in the diagram above. The hole center is obtained by measuring the distance namely  $5 \frac{1}{16}$ " for left and right hole respectively.
  - Drill the piping hole at either the right or the left and the hole should be slightly slanting to the outdoor side.


#### 10.1.3.2 To Drill a Hole in the Wall and Install a Sleeve of Piping

- 1 Insert the piping sleeve to the hole.
- 2 Fix the bushing to the sleeve.
- 3 Cut the sleeve until it extrudes about  $19/32$ " from the wall.


#### ⚠ CAUTION

When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connecting cable.

- 4 Finish by sealing the sleeve with putty or caulking compound at the final stage.



### 10.1.3.3 Indoor Unit Installation



### 10.1.3.4 For the right rear piping


- Step-1** Pull out the Indoor piping
- Step-2** Install the Indoor Unit
- Step-3** Secure the Indoor Unit
- Step-4** Insert the connecting cable

### 10.1.3.5 For the right bottom piping


- Step-1** Pull out the Indoor piping
- Step-2** Install the Indoor Unit
- Step-3** Insert the connecting cable
- Step-4** Secure the Indoor Unit

### 10.1.3.6 For the embedded piping

- Step-1** Replace the drain hose
- Step-2** Bend the embedded piping
  - Use a spring bender or equivalent to bend the piping so that the piping is not crushed.
- Step-3** Pull the connecting cable into Indoor Unit
  - The inside and outside connecting cable can be connected without removing the front grille.
- Step-4** Cut and flare the embedded piping
  - When determining the dimensions of the piping, slide the unit all the way to the left on the installation plate.
  - Refer to the section "Cutting and flaring the piping".
- Step-5** Install the Indoor Unit
- Step-6** Connect the piping
  - Please refer to "Connecting the piping" column in outdoor unit section. (Below steps are done after connecting the outdoor piping and gas-leakage confirmation.)
- Step-7** Insulate and finish the piping
  - Please refer to "Piping and finishing" column of outdoor section and "Insulation of piping connection" column as mentioned in indoor/outdoor unit installation.
- Step-8** Secure the Indoor Unit



(This can be used for left rear piping and bottom piping also.)




### 10.1.3.7 Connect the Cable to the Indoor Unit


- The inside and outside connecting cable can be connected without removing the front grille.
- Unscrew the conduit cover and fix the conduit connector to conduit cover with lock nut, then secure it against chassis.
- Connecting wire between indoor unit and outdoor unit should be UL listed or CSA approved 4 conductor wires minimum AWG16 in accordance with local electric codes.
  - Ensure the colour of wires of outdoor unit and terminal number are the same as the indoor's respectively.

Terminals on the indoor unit	1	2	3	
Colour of wires (connecting wire)				
Terminals on the outdoor unit	1	2	3	

- ⚡ This equipment must be properly earthed.
  - Earth lead wire shall be Yellow/Green (Y/G) in colour and shall be longer than other lead wires as shown in the figure for electrical safety in case of the slipping.




### 10.1.3.8 Wire Stripping and connecting requirement



### 10.1.3.9 Cutting and flaring the piping


- 1 Please cut using pipe cutter and then remove the burrs.
- 2 Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- 3 Please make flare after inserting the flare nut onto the copper pipes.



## 10.1.4 Outdoor Unit

### 10.1.4.1 Install the Outdoor Unit

- After selecting the best location, start installation to Indoor/Outdoor Unit Installation Diagram.
  - Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut (ø13/32").
  - When installing at roof, please consider strong wind and earthquake.  
Please fasten the installation stand firmly with bolt or nails.



Model	A	B	C	D
S9NKUW-1, S12NKUW-1	22 7/16"	4 1/8"	23/32"	12 19/32"

### 10.1.4.2 Connect the Piping


#### 10.1.4.2.1 Connecting the piping to indoor

Please make flare after inserting flare nut (locate at joint portion of tube assembly) onto the copper pipe.  
(In case of using long piping)

Connect the piping

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.

Do not over tighten, over tightening may cause gas leakage.	
Piping size	Torque
1/4"	13.3 lbf.ft
3/8"	31.0 lbf.ft
1/2"	40.6 lbf.ft
5/8"	47.9 lbf.ft
3/4"	73.8 lbf.ft




#### 10.1.4.2.2 Connecting the piping to outdoor

Decide piping length and then cut by using pipe cutter.  
Remove burrs from cut edge.  
Make flare after inserting the flare nut (locate at valve)  
onto the copper pipe.  
Align center of piping to valve and then tighten with  
torque wrench to the specified torque as stated in the  
table.

#### 10.1.4.2.3 Connecting the piping to outdoor multi

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge.  
Make flare after inserting the flare nut (locate at valve) onto the copper pipe.  
Align center of piping to valve and then tighten with torque wrench to the specified torque as stated in the table.






#### 10.1.4.2.4 Gas leak checking

Pressure test to system to 400 PSIG with dry nitrogen, in stages. Thoroughly leak check the system. If the pressure holds, release the nitrogen and proceed to section 10.1.4.3.

#### 10.1.4.3 Evacuation of the equipment

When installing an air conditioner, be sure to evacuate the air inside the indoor unit and pipes in the following procedures.




1. Connect a charging hose with a push pin to the Low side of a charging set and the service port of the 3-way valve.
2. Connect the micron gauge between vacuum pump and service port of outdoor units.
3. Turn on the power switch of the vacuum pump and make sure that connect digital micron gauge and to pull down to a value of 500 microns.
4. To make sure micron gauge a value 500 microns and close the low side valve of the charging set and turn off the vacuum pump.
5. Disconnect the vacuum pump hose from the service port of the 3-way valve.
6. Tighten the service port caps of the 3-way valve at a torque of 13.3 lbf.ft with a torque wrench.
7. Remove the valve caps of both of the 2-way valve and 3-way valve. Position both of the valves to "Open" using a hexagonal wrench (5/32").
8. Mount valve caps onto the 2-way valve and the 3-way valve.
  - Be sure to check for gas leakage.


#### ⚠ CAUTION

- If micron gauge value does not descend 500 microns, take the following measures:
  - If the leak stops when the piping connections are tightened further, continue working from step ③.
  - If the leak does not stop when the connections are retightened, repair location of leak.
  - Do not release refrigerant during piping work for installation and reinstallation.
  - Be careful with the liquid refrigerant, it may cause frostbite.


#### 10.1.4.4 Connect the Cable to the Outdoor Unit

1. Remove Top panel.
2. Remove Control Board Cover (Resin and Metal).
3. Remove Plugs.
4. Fix the conduit connectors to the knockout holes with lock-nuts, then secure them against the side panel.
5. All wires pass through conduits.
6. Connecting wire between indoor unit and outdoor unit should be UL listed or CSA approved 4 conductor wires minimum AWG16 in accordance with local electric codes.
7. Wire connection to the power supply (208/230V 60Hz) through circuit breaker.
  - Connect the UL listed or CSA approved wires minimum AWG14 to the terminal board, and connect the other end of the wires to ELCB / GFCI.
8. Connect the power supply cord and connecting wire between indoor unit and outdoor unit according to the diagram below.





9. Secure the wire onto the control board with the holder (clammer).
10. After completing wiring connections, reattach the control board cover (Metal and Resin) and the top panel to the original position with the screws.
11. For wire stripping and connection requirement, refer to instruction ⑤ of indoor unit.
  - ⚠ This equipment must be properly earthed.
    - Earth lead wire shall be Yellow/Green (Y/G) in colour and shall be longer than other lead wires as shown in the figure for electrical safety in case of the slipping.



#### 10.1.4.5 Piping Insulation

1. Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.
2. If drain hose or connecting piping is in the room (where dew may form), please increase the insulation by using POLY-E FOAM with thickness 1/4" or above.

## 10.2 S18NKU-1 S22NKU-1

### 10.2.1 Select the Best Location

#### 10.2.1.1 Indoor Unit

- Do not install the unit in excessive oil fume areas such as kitchens, workshops etc.
- There should not be any heat source or steam near the unit.
- There should not be any obstacles blocking the air circulation.
- A place where air circulation in the room is good.
- A place where drainage can be easily done.
- A place where noise prevention is taken into consideration.
- Do not install the unit near a doorway.
- Ensure the spaces indicated by arrows from the wall, ceiling, fence or other obstacles.
- Recommended installation height for indoor unit shall be at least 8.2 ft.

#### 10.2.1.2 Outdoor Unit


- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- There should not be any animal or plant which could be affected by hot air discharged.
- Keep the spaces indicated by arrows from wall, ceiling, fence or other obstacles.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If piping length is over the [piping length for additional gas], additional refrigerant should be added as shown in the table.
- Recommended installation height for outdoor unit should be above the seasonal snow level.

Model	Capacity (Btu/h)	Piping size		Std. Length (ft)	Max. Eleva- tion (ft)	Min. Piping Length (ft)	Max. Piping Length (ft)	Additional Refrige- rant (oz/ft)	Piping Length for add. gas (ft)
		Gas	Liquid						
S18NKU-1	17100	1/2"	1/4"	16.4	49.2	9.8	65.6	0.2	32.8
S22NKU-1	21000	5/8"	1/4"		49.2	9.8	65.6	0.2	32.8

Example: For S18NKU-1

If the unit is installed at 41 ft distance, the quantity of additional refrigerant should be 1.64 oz .... (41 - 32.8) ft x 0.2 oz/ft = 1.64 oz.


### 10.2.2 Indoor/Outdoor Unit Installation Diagram



## 10.2.3 Indoor Unit

### 10.2.3.1 How to Fix Installation Plate

The mounting wall must be strong and solid enough to prevent it from the vibration.



Model	Dimension					
	①	②	③	④	⑤	⑥
S18NKU-1, S22NKU-1	23 1/32"	3 7/32"	6 1/2"	6 7/32"	6 21/32"	8 5/8"

The centre of installation plate should be at more than ① at right and left of the wall.

The distance from installation plate edge to ceiling should more than ②.

From installation plate left edge to unit's left side is ③.

From installation plate right edge to unit's right side is ④.

- Ⓑ : For left side piping, piping connection for liquid should be about ⑤ from this line.  
 : For left side piping, piping connection for gas should be about ⑥ from this line.

- 1 Mount the installation plate on the wall with 5 screws or more (at least 5 screws).  
 (If mounting the unit on the concrete wall, consider using anchor bolts.)
  - Always mount the installation plate horizontally by aligning the marking-off line with the thread and using a level gauge.
- 2 Drill the piping plate hole with  $\varnothing 2 \frac{3}{4}$ " hole-core drill.
  - Line according to the left and right side of the installation plate. The meeting point of the extended line is the center of the hole. Another method is by putting measuring tape at position as shown in the diagram above. The hole center is obtained by measuring the distance namely  $5 \frac{1}{16}$ " for left and right hole respectively.
  - Drill the piping hole at either the right or the left and the hole should be slightly slanting to the outdoor side.


### 10.2.3.2 To Drill a Hole in the Wall and Install a Sleeve of Piping

- 1 Insert the piping sleeve to the hole.
- 2 Fix the bushing to the sleeve.
- 3 Cut the sleeve until it extrudes about  $19/32$ " from the wall.


#### ⚠ CAUTION

When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connecting cable.

- 4 Finish by sealing the sleeve with putty or caulking compound at the final stage.



### 10.2.3.3 Indoor Unit Installation



### 10.2.3.4 For the right rear piping


- Step-1** Pull out the Indoor piping
- Step-2** Install the Indoor Unit
- Step-3** Secure the Indoor Unit
- Step-4** Insert the connecting cable

### 10.2.3.5 For the right bottom piping


- Step-1** Pull out the Indoor piping
- Step-2** Install the Indoor Unit
- Step-3** Insert the connecting cable
- Step-4** Secure the Indoor Unit

### 10.2.3.6 For the embedded piping

- Step-1** Replace the drain hose
- Step-2** Bend the embedded piping
  - Use a spring bender or equivalent to bend the piping so that the piping is not crushed.
- Step-3** Pull the connecting cable into Indoor Unit
  - The inside and outside connecting cable can be connected without removing the front grille.
- Step-4** Cut and flare the embedded piping
  - When determining the dimensions of the piping, slide the unit all the way to the left on the installation plate.
  - Refer to the section "Cutting and flaring the piping".
- Step-5** Install the Indoor Unit
- Step-6** Connect the piping
  - Please refer to "Connecting the piping" column in outdoor unit section. (Below steps are done after connecting the outdoor piping and gas-leakage confirmation.)
- Step-7** Insulate and finish the piping
  - Please refer to "Piping and finishing" column of outdoor section and "Insulation of piping connection" column as mentioned in indoor/outdoor unit installation.
- Step-8** Secure the Indoor Unit



(This can be used for left rear piping and bottom piping also.)




### 10.2.3.7 Connect the Cable to the Indoor Unit


- The inside and outside connecting cable can be connected without removing the front grille.
- Unscrew the conduit cover and fix the conduit connector to conduit cover with lock nut, then secure it against chassis.
- Connecting wire between indoor unit and outdoor unit should be UL listed or CSA approved 4 conductor wires minimum AWG16 in accordance with local electric codes.
  - Ensure the colour of wires of outdoor unit and terminal number are the same as the indoor's respectively.

Terminals on the indoor unit	1	2	3	
Colour of wires (connecting wire)				
Terminals on the outdoor unit	1	2	3	

- ⚡ This equipment must be properly earthed.
  - Earth lead wire shall be Yellow/Green (Y/G) in colour and shall be longer than other lead wires as shown in the figure for electrical safety in case of the slipping.




### 10.2.3.8 Wire Stripping and connecting requirement



### 10.2.3.9 Cutting and flaring the piping


- 1 Please cut using pipe cutter and then remove the burrs.
- 2 Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- 3 Please make flare after inserting the flare nut onto the copper pipes.



## 10.2.4 Outdoor Unit

### 10.2.4.1 Install the Outdoor Unit

- After selecting the best location, start installation to Indoor/Outdoor Unit Installation Diagram.
  - Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut ( $\phi 13/32"$ ).
  - When installing at roof, please consider strong wind and earthquake.  
Please fasten the installation stand firmly with bolt or nails.



Model	A	B	C	D
S18NKU-1, S22NKU-1	24 1/8"	5 5/32"	5/8"	14 3/32"

### 10.2.4.2 Connect the Piping

#### 10.2.4.2.1 Connecting the piping to indoor


Please make flare after inserting flare nut (locate at joint portion of tube assembly) onto the copper pipe.  
(In case of using long piping)

Connect the piping

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.

Do not over tighten, over tightening may cause gas leakage.

Piping size	Torque
1/4"	13.3 lbf.ft
3/8"	31.0 lbf.ft
1/2"	40.6 lbf.ft
5/8"	47.9 lbf.ft
3/4"	73.8 lbf.ft



#### 10.2.4.2.2 Connecting the piping to outdoor

Decide piping length and then cut by using pipe cutter.  
Remove burrs from cut edge.  
Make flare after inserting the flare nut (locate at valve) onto the copper pipe.  
Align center of piping to valve and then tighten with torque wrench to the specified torque as stated in the table.


#### 10.2.4.2.3 Gas leak checking

Pressure test to system to 400 PSIG with dry nitrogen, in stages. Thoroughly leak check the system.  
If the pressure holds, release the nitrogen and proceed to section 10.2.4.3.



#### 10.2.4.3 Evacuation of the equipment

When installing an air conditioner, be sure to evacuate the air inside the indoor unit and pipes in the following procedures.




1. Connect a charging hose with a push pin to the Low side of a charging set and the service port of the 3-way valve.
2. Connect the micron gauge between vacuum pump and service port of outdoor units.
3. Turn on the power switch of the vacuum pump and make sure that connect digital micron gauge and to pull down to a value of 500 microns.
4. To make sure micron gauge a value 500 microns and close the low side valve of the charging set and turn off the vacuum pump.
5. Disconnect the vacuum pump hose from the service port of the 3-way valve.
6. Tighten the service port caps of the 3-way valve at a torque of 13.3 lbf.ft with a torque wrench.
7. Remove the valve caps of both of the 2-way valve and 3-way valve. Position both of the valves to "Open" using a hexagonal wrench (5/32").
8. Mount valve caps onto the 2-way valve and the 3-way valve.
  - Be sure to check for gas leakage.

#### CAUTION


- If micron gauge value does not descend 500 microns, take the following measures:
  - If the leak stops when the piping connections are tightened further, continue working from step ③.
  - If the leak does not stop when the connections are retightened, repair location of leak.
  - Do not release refrigerant during piping work for installation and reinstallation.
  - Be careful with the liquid refrigerant, it may cause frostbite.

#### 10.2.4.4 Connect the Cable to the Outdoor Unit

1. Remove control board cover (Resin and Metal).
2. Remove particular plate.
3. Remove plugs.
4. Fix the conduit connectors to the knockout holes with lock-nuts, then secure them against the side panel.
5. All wires pass through conduits & particular plate's opening hole.
6. Connecting wire between indoor unit and outdoor unit should be UL listed or CSA approved 4 conductor wires minimum AWG16 in accordance with local electric codes.
7. Wire connection to the power supply (208/230V 60Hz) through circuit breaker.
  - Connect the UL listed or CSA approved wires minimum AWG12 to the terminal board, and connect the other end of the wires to ELCB / GFCI.
8. Connect the power supply cord and connecting wire between indoor unit and outdoor unit according to the diagram below.



9. Secure the wire onto the control board with the holder (clammer).
10. After completing wiring connections, reattach the particular plate and control board cover (metal and resin) to the original position with the screws.
11. For wire stripping and connection requirement, refer to instruction ⑤ of indoor unit.
  - ⊕ This equipment must be properly earthed.
    - Earth lead wire shall be Yellow/Green (Y/G) in colour and longer than other lead wires for electrical safety in case of the slipping.



#### 10.2.4.5 Piping Insulation

1. Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.
2. If drain hose or connecting piping is in the room (where dew may form), please increase the insulation by using POLY-E FOAM with thickness  $\frac{1}{4}$ " or above.


# 11. Operation Control

## 11.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operation mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operation mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal setting temperature and intake air temperature.

### 11.1.1 Internal Setting Temperature

Once the operation starts, remote control setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the air conditioner settings and the operation environment. The final shifted value will be used as internal setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.



### 11.1.2 Cooling Operation

#### 11.1.2.1 Thermostat control

- Compressor is OFF when intake Air Temperature - Internal Setting Temperature < 29.3°F.
- Compressor is ON after waiting for 3 minutes, if the Intake Temperature - Internal Setting Temperature > Compressor OFF point.


### 11.1.3 Soft Dry Operation

#### 11.1.3.1 Thermostat control

- Compressor is OFF when Intake Temperature - Internal Setting Temperature < 28.4°F.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature - Internal Setting Temperature > Compressor OFF point.

#### 11.1.3.2 Automatic Operation

- This mode can be set using remote control and the operation is decided by indoor intake air temperature.
- During operation mode judgment at the beginning of the Auto Mode operation, indoor fan motor (with speed of Lo-) is running for 30 seconds to detect the indoor intake air temperature.
- The operation mode is decided based on below chart.



- After the operation mode is decided, the unit operation will follow the respective operation mode control.


## 11.2 Indoor Fan Motor Operation

### 11.2.1 Basic Rotation Speed

- Manual Fan Speed
  - Fan motor's number of rotation is determined according to remote control setting.

Remote control	○	○	○	○	○
Tab	Hi	Me+	Me	Me-	Lo


- Auto Fan Speed
  - According to room temperature and setting temperature, indoor fan speed is determined automatically.
  - The indoor fan will operate according to pattern below.



- Feedback control
  - Immediately after the fan motor is started, feedback control is performed once every second.
  - During fan motor on, if fan motor feedback  $\geq 2550$  rpm or  $<50$  rpm continuously for 10 seconds, the fan motor error counter increased; fan motor is then stopped and restarted. If the fan motor error counter increased to 7, then H19 – fan motor error is detected. Operation stopped and could not be restarted.


## 11.3 Outdoor Fan Motor Operation (For S9NK and S12NK)

Outdoor fan motor is operated with one fan speed only. Outdoor fan turns on when compressor starts to operate. But outdoor fan will turns off 30 seconds after compressor stops to operate.



## 11.4 Outdoor Fan Motor Operation (For S18NK and S22NK)

There is 2 speeds for outdoor fan motor. Outdoor fan speed can be changed to Hi or Shi according to outdoor temperature. By default, the outdoor fan speed is set to Hi. For Cooling or Soft Dry operation, when outdoor temperature reaches 100.4°F the outdoor fan speed is set to Shi, when outdoor temperature reduced to 98.6°F the fan speed will set to Hi again. Outdoor fan will turns off 30 seconds after compressor stops to operate.




## 11.5 Airflow Direction

- There are two types of airflow, vertical airflow (directed by horizontal vane) and horizontal airflow (directed by vertical vanes).
- Control of airflow direction can be automatic (angles of direction is determined by operation mode, heat exchanger temperature and intake air temperature) and manual (angles of direction can be adjusted using remote control).

### 11.5.1 Vertical Airflow

Operation Mode	Airflow Direction	Vane Angle (°)				
		1	2	3	4	5
Cooling	Auto	20 ~ 45				
	Manual	20	26	32	37	45
Soft Dry	Auto	20 ~ 45				
	Manual	20	26	32	37	45

- Automatic vertical airflow direction can be set using remote control; the vane swings up and down within the angles as stated above. It does not swing during fan motor stop. When the air conditioner is stopped using remote control, the vane will shift to close position.
- Manual vertical airflow direction can be set using remote control; the angles of the vane are as stated above and the positions of the vane are as figure below. When the air conditioner is stopped using remote control, the vane will shift to close position.



### 11.5.2 Horizontal Airflow

#### 11.5.2.1 S9NK, S12NK


The horizontal airflow direction louvers can be adjusted manually by hand.

#### 11.5.2.2 S18NK, S22NK

- Automatic airflow direction can be set using remote control; the vane swings left and right within the angles as stated below. It does not swing during fan motor stop.

Operation Mode	Vane Angle (°)
Cooling and soft dry	68 ~112

- Manual vertical airflow direction can be set using remote control; the angles of the vane are as stated below and the positions of the vane are as figure below:



Pattern	1	2	3	4	5
Airflow Direction Patterns at Remote Control					
Vane Angle (°)	90	68	78	102	112

## 11.6 Quiet Operation (Cooling Mode/Cooling Area of Dry Mode)

- Purpose
  - To provide quiet cooling operation compare to normal operation.
- Control condition
  - Quiet operation start condition
    - When Quiet button at remote control is pressed Quiet INDICATOR illuminates.
  - Quiet operation stop condition
    - When one of the following conditions is satisfied, quiet operation stops:
      - Powerful button is pressed.
      - Stop by OFF/ON button.
      - OFF Timer activates.
      - Quiet button is pressed again.

- When quiet operation is stopped, operation is shifted to normal operation with previous setting.
  - When fan speed is changed, quiet operation is shifted to quiet operation of the new fan speed.
  - When operation mode is changed, quiet operation is shifted to quiet operation of the new mode.
  - During quiet operation, if ON timer activates, quiet operation maintains.
  - After off, when on back, quiet operation is not memorized.
- Control content
    - Fan speed is changed from normal setting to quiet setting of respective fan speed. This is to reduce sound of Hi, Me, Lo for 3dB (more than 3dB for some models).
    - Fan speed for quiet operation is -1 step from setting fan speed.

## 11.7 Powerful Mode Operation

- When the powerful mode is selected, the internal setting temperature will shift lower up to 35.6°F (for Cooling/Soft Dry) than remote control setting temperature for 20 minutes and the fan speed will increase to achieve the setting temperature quickly.
- Powerful operation stops condition
  - When one of the following condition is satisfied, powerful operation stops:
    - Quiet button is pressed.
    - Stop by OFF/ON button.
    - OFF Timer activates.
    - Powerful button is pressed again.
    - Powerful operation continue for 20 minutes.


## 11.8 Timer Control

### 11.8.1 ON Timer Control

ON timer can be set using remote control, the unit with timer set will start operate earlier than the setting time. This is to provide a comfortable environment when reaching the set ON time.

60 minutes before the set time, indoor (at fan speed of Lo-) and outdoor fan motor start operate for 30 seconds to determine the indoor intake air temperature and outdoor air temperature in order to judge the operation starting time.

From the judgment, the decided operation will start operation earlier than the set time as shown below.



### 11.8.2 OFF Timer Control

OFF timer can be set using remote control, the unit with timer set will stop operate at set time.

## 11.9 Random Auto Restart Control

- When the power supply is cut off during the operation of air conditioner, the compressor will re-operate within three to four minutes. There are 10 patterns to be selected randomly after power supply resumes.
- This control is not applicable during OFF/ON Timer setting.

## 11.10 Indication Panel

LED	POWER	TIMER	QUIET	POWERFUL
Color	Green	Orange	Orange	Orange
Light ON	Operation ON	Timer Setting ON	Quiet Mode ON	Powerful Mode ON
Light OFF	Operation OFF	Timer Setting OFF	Quiet Mode OFF	Powerful Mode OFF

Note:

- If POWER LED blinks, the possible operation of the unit is operation mode judgment, or ON timer sampling.
- If TIMER LED blinks, there is an abnormal operation occurs.

## 12. Protection Control

### 12.1 Restart Control (Time Delay Safety Control)

- The compressor will not turn on within 3 minutes from the moment operation stops, although the unit is turned on again by pressing OFF/ON button at remote control within this period.
- This control is not applicable if the power supply is cut off and on again.
- This phenomenon is to balance the pressure inside the refrigerant cycle.

### 12.2 30 Seconds Forced Operation


- Once the air conditioner is turned on, the compressor will not stop within 30 seconds in a normal operation although the intake air temperature has reached the thermo-off temperature. However, force stop by pressing the OFF/ON button at the remote control is permitted or the Auto OFF/ON button at indoor unit.
- The reason for the compressor to force operation for minimum 30 seconds is to allow the refrigerant oil run in a full cycle and return back to the outdoor unit.

### 12.3 Total Running Current Control


- When the outdoor unit total running current (AC) exceeds X value, the frequency instructed for compressor operation will be decreased.
- If the running current does not exceed X value for 5 seconds, the frequency instructed will be increased.

Model	S9***	S12***	S18***	S22***
Operation Mode	X (A)	X (A)	X (A)	X (A)
Cooling / Soft Dry (A)	3.89	5.19	8.77	11.05
Cooling / Soft Dry (B)	3.28	4.63	7.72	9.55

- The first 30 minutes of cooling operation, (A) will be applied.



S9NK, S12NK



S18NK, S22NK

### 12.4 IPM (Power Transistor) Prevention Control

#### 12.4.1 S9NK, S12NK

- Overheating Prevention Control
  - When the IPM temperature rises to 212°F, compressor operation will stop immediately.
  - Compressor operation restarts after 3 minutes the temperature decreases to 203°F.
- DC Peak Current Control
  - When electric current to IPM exceeds set value of 18.5A, the compressor will stop operate. Then, operation will restart after 3 minutes.
  - If the set value exceeds again more than 30 seconds after the compressor starts, the operation will restart after 2 minutes.
  - If the set value exceeds again within 30 seconds after the compressor starts, the operation will restart after 1 minute. If this condition repeats continuously for 7 times, all indoor and outdoor relays will be cut off.
  - Timer LED will be blinking (F99 is indicated).




### 12.4.2 S18NK, S22NK

- Overheating Prevention Control
  - When the IPM temperature rises to 212°F, compressor operation will stop immediately.
  - Compressor operation restarts after 3 minutes the temperature decreases to 203°F.
- DC Peak Current Control
  - When electric current to IPM exceeds set value of 29.9A, the compressor will stop operate. Then, operation will restart after 3 minutes.
  - If the set value is exceeded again more than 30 seconds after the compressor starts, the operation will restart after 2 minute.
  - If the set value is exceeded again within 30 seconds after the compressor starts, the operation will restart after 1 minute. If this condition repeats continuously for 7 times, all indoor and outdoor relays will be cut off.

### 12.5 Compressor Overheating Prevention Control (For S18, S22NK only)

- Instructed frequency for compressor operation will be regulated by compressor discharge temperature. The changes of frequency are as below.
- If compressor discharge temperature exceeds 233.6°F, compressor will be stopped, occurs 4 times per 20 minutes, timer LED will be blinking. "F97" is indicated.



### 12.6 Low Pressure Protection Control (Gas Leakage Detection)

- Control start conditions
  - For 5 minutes, the compressor continuously operates and outdoor total current is between 0.66A and 1.25A (S9NK and S12NK) or 0.81A and 1.23A (S18NK and S22NK).
  - During Cooling and Soft Dry operation:  
Indoor suction temperature – indoor piping temperature is below 39.2°F
- Control contents
  - Compressor stops (and restart after 3 minutes).
  - If the conditions above happened 2 times within 20 minutes, the unit will:
    - Stop operation
    - Timer LED blinks and "F91" indicated.

### 12.7 Low Frequency Protection Control 1

- When the compressor operates at frequency lower than 26Hz continued for 20 minutes, the operation frequency will be changed to 25Hz for 2 minutes. (For S9NK and S12NK)
- When the compressor operates at frequency lower than 25Hz continued for 240 minutes, the operation frequency will be change to 24Hz for 2 minutes. (For S18NK and S22NK)


### 12.8 Low Frequency Protection Control 2

- When all below conditions comply, minimum limit of compressor frequency will be set.

Temperature, T, for:	Cooling / Soft Dry	
	S9NK and S12NK	S18NK and S22NK
Indoor intake air (°F)	T < 59 or T ≥ 86	T < 57.2 or ≥ 86
Outdoor air (°F)	T < 60.8 or T ≥ 100.4	T < 55.4 or T ≥ 100.4
Indoor heat exchanger (°F)	T < 86	T < 86

## 12.9 Outdoor Air Temperature Control

- The compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust based on outdoor air temperature.



## 12.10 Cooling Overload Control

- Pipe temperature limitation / restriction.
  - Detects the outdoor pipe temperature and carry out restriction / limitation below (Limit the compressor operation frequency)
  - The compressor stops if outdoor pipe temperature exceeds 141.8°F (for S9NK and S12NK), 145.4°F (for S18NK and S22NK).
  - If the compressor stops 4 times in 20 minutes, Timer LED blinks ("F95" indicated: Outdoor high pressure rise protection)

## 12.11 Freeze Prevention Control

- When indoor heat exchanger temperature is lower than 32°F continuously for 6 minutes, compressor will stops operation.
- Compressor will resume its operation 3 minutes after the indoor heat exchanger is higher than 55.4°F.
- At the same time, indoor fan speed will be higher than during its normal operation.
- If the indoor heat exchanger temperature is higher than 55.4°F for 5 minutes, the fan speed will return to its normal operation.

## 12.12 Freeze Prevention Control 2


- Control start conditions
  - During Cooling operation and soft dry operation
    - During thermo OFF condition, indoor intake temperature is less than 50°F or
    - Compressor stops for freeze prevention control
  - Either one of the conditions above occurs 5 times in 60 minutes.
- Control contents
  - Operation stops
  - Timer LED blinks and "H99" indicated

## 12.13 Dew Prevention Control

- To prevent dew formation at indoor unit discharge area.
- This control will be activated if:
  - Cooling mode or Quiet mode is activated.
  - Remote control setting temperature is less than 77°F.
  - Fan Speed is at CLo or QLo.
  - Room temperature is constant ( $\pm 33.8^\circ\text{F}$ ) for 30 minutes.
  - Compressor is continuously running.
- Fan speed will be adjusted accordingly in this control.
  - Fan speed will be increased slowly if the unit is in quiet mode but no change in normal cooling mode.

## 13. Servicing Mode

### 13.1 Auto Off/On Button




#### 1 AUTO OPERATION MODE

The Auto Operation will be activated immediately once the Auto OFF/ON button is pressed. This operation can be used to operate air conditioner with limited function if remote control is misplaced or malfunction.

#### 2 TEST RUN OPERATION (FOR PUMP DOWN/SERVICING PURPOSE)

The Test Run Operation will be activated if the Auto OFF/ON button is pressed continuously for more than 5 seconds. A “beep” sound will be heard at the fifth seconds, in order to identify the starting of this operation.

The Auto OFF/ON button may be used together with remote control to set / change the advance setting of air conditioner operation.



#### 3 REMOTE CONTROL NUMBER SWITCH MODE

The Remote Control Number Switch Mode will be activated if the Auto OFF/ON button is pressed continuously for more than 11 seconds (3 “beep” sounds will occur at 11<sup>th</sup> seconds to identify the Remote Control Number Switch Mode is in standby condition), press “AC Reset” button and then press any button at remote control to transmit and store the desired transmission code to the EEPROM.

There are 4 types of remote control transmission code could be selected. The indoor unit will only operate when received signal with same transmission code from remote control. This could prevent signal interference when there are 2 or more units installed nearby together.

To change remote control transmission code, short or open jumpers at the remote control printed circuit board.

Remote Control Printed Circuit Board		
Jumper A (J-A)	Jumper B (J-B)	Remote Control No.
Short	Open	A (Default)
Open	Open	B
Short	Short	C
Open	Short	D

#### 4 REMOTE CONTROL RECEIVING SOUND OFF/ON MODE

The Remote Control Receiving Sound OFF/ON Mode will be activated if the Auto OFF/ON button is pressed continuously for more than 16 seconds (4 “beep” sounds will occur at 16<sup>th</sup> seconds to identify the Remote Control Receiving Sound OFF/ON Mode is in standby condition) and press “AC Reset” button and then press “Check” button at remote control.

Press Auto OFF/ON button to toggle remote control receiving sound.

- Short “beep”: Turn ON remote control receiving sound.
- Long “beep”: Turn OFF remote control receiving sound.

After Auto OFF/ON button is pressed, the 20 seconds counter for Remote Control Receiving Sound OFF/ON Mode is restarted.

## **13.2 Remote Control Button**

### **13.2.1 SET Button**

- To check remote control transmission code and store the transmission code to EEPROM
  - Press “Set” button continuously for 10 seconds by using pointer
  - Press “Timer Set” button until a “beep” sound is heard as confirmation of transmission code change.

### **13.2.2 RESET (RC)**

- To clear and restore the remote control setting to factory default.
  - Press once to clear the memory

### **13.2.3 RESET (AC)**

- To restore the unit's setting to factory default.
  - Press once to restore the unit's setting

### **13.2.4 TIMER ▲**

- To change indoor unit indicators' intensity:
  - Press continuously for 5 seconds.

### **13.2.5 TIMER ▼**

- To change remote control display from Degree Celsius (°C) to Degree Fahrenheit (°F)
  - Press continuously for 10 seconds.

## 14. Troubleshooting Guide


### 14.1 Refrigeration Cycle System

In order to diagnose malfunctions, ensure the air conditioner is free from electrical problems before inspecting the refrigeration cycle. Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan. The normal outlet air temperature and pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table to the right.

Normal Pressure and Outlet Air Temperature (Standard)

	Gas Pressure PSI (kg/cm <sup>2</sup> G)	Outlet air Temperature (°F)
Cooling Mode	130.5 ~ 174.0 (9 ~ 12)	53.6 ~ 60.8

Condition: Indoor fan speed = High  
Outdoor temperature = 95°F at cooling mode.  
Compressor operate at rated frequency



### 14.1.1 Relationship between the condition of the air conditioner and pressure and electric current

Condition of the air conditioner	Cooling Mode		
	Low Pressure	High Pressure	Electric current during operation
Insufficient refrigerant (gas leakage)	↘	↘	↘
Clogged capillary tube or strainer	↘	↘	↘
Short circuit in the indoor unit	↘	↘	↘
Heat radiation deficiency of the outdoor unit	↗	↗	↗
Inefficient compression	↗	↘	↘

- Carry out the measurement of pressure, electric current, and temperature fifteen minutes after an operation is started.

## 14.2 Breakdown Self Diagnosis Function

### 14.2.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- Once error occurred during operation, the unit will stop its operation, and Timer LED blinks.
- Although Timer LED goes off when power supply is turned off, if the unit is operated under a breakdown condition, the LED will ON again.
- In operation after breakdown repair, the Timer LED will not blink. The last error code (abnormality) will be stored in IC memory.

### 14.2.2 To Make a Diagnosis

- 1 Timer LED starts to blink and the unit automatically stops the operation.
- 2 Press the CHECK button on the remote control continuously for 5 seconds.
- 3 “- -” will be displayed on the remote control display.  
Note: Display only for “- -” (No signal transmission, no receiving sound and no Power LED blinking)
- 4 Press the TIMER ▲ or ▼ button on the remote control. The code “H00” (no abnormality) will be displayed and signal will be transmit to the main unit.
- 5 Each press of the button (▲ or ▼) will increase error code number and transmit error code signal to the main unit.
- 6 When the latest abnormality code on the main unit and code transmitted from the remote control are matched, Power LED will light up for 30 seconds and a “beep” sound (continuously for 4 seconds) will be heard. If no codes are matched, Power LED will light up for 0.5 seconds and no sound will be heard.
- 7 The breakdown diagnosis mode will be canceled unless pressing the CHECK button continuously for 5 seconds or operating the unit for 30 seconds.
- 8 The LED will be off if the unit is turned off or the RESET button on the main unit is pressed.



### 14.2.3 To Display Memorized Error Code (Protective Operation)

- 1 Turn power on.
- 2 Press the CHECK button on the remote control
- 3 “- -” will be displayed on the remote control display.  
Note: Display only for “- -” (No signal transmission, no receiving sound and no Power LED blinking)
- 4 Press the TIMER ▲ or ▼ button on the remote control. The code “H00” (no abnormality) will be displayed and signal will be transmit to the main unit.
- 5 Each press of the button (▲ or ▼) will increase error code number and transmit error code signal to the main unit.
- 6 When the latest abnormality code on the main unit and code transmitted from the remote control are matched, Power LED will light up for 30 seconds and a “beep” sound (continuously for 4 seconds) will be heard. If no codes are matched, Power LED will light up for 0.5 seconds and no sound will be heard.
- 7 The breakdown diagnosis mode will be canceled unless pressing the CHECK button continuously for 5 seconds or operating the unit for 30 seconds.
- 8 The same diagnosis can be repeated by turning power on again.

### 14.2.4 To Clear Memorized Error Code after Repair (Protective Operation)

- 1 Turn power on (in standby condition).
- 2 Press the AUTO button for 5 seconds (a “beep” sound is heard) on the main unit to operate the unit at Forced Cooling Operation Mode.
- 3 Press the CHECK button on the remote control for about 1 second with a pointed object to transmit signal to main unit. A “beep” sound is heard, and the Error Code is cleared.

### 14.2.5 Temporary Operation (Depending On Breakdown Status)

- 1 Press the Auto OFF/ON button on the main unit (a “beep” sound is heard) to operate the unit. (Remote control is enable again).
- 2 The unit can be temporarily be used until repaired.

Error Code	Operation	Temporary items
H23	Cooling	Emergency Operation with limited power
H27, H28	Cooling	

## 14.3 Error Code Table

Diagnosis display	Abnormality / Protection control	Abnormality Judgment	Emergency Operation	Primary location to verify
H00	No abnormality detected	-	Normal operation	
H11	Indoor / Outdoor abnormal communication	> 1 min after starting operation	Indoor fan operation only	<ul style="list-style-type: none"> <li>Internal / external cable connection</li> <li>Indoor / outdoor PCB</li> </ul>
H12	Connection capability rank abnormality	Continuously for 90 sec after power supplied	-	-
H14	Indoor intake air temperature sensor abnormality	Continue for 5 sec.	-	<ul style="list-style-type: none"> <li>Intake air temperature sensor (defective or disconnected)</li> </ul>
H15	Outdoor compressor temperature sensor abnormality	Continue for 5 sec.	-	<ul style="list-style-type: none"> <li>Compressor temperature sensor (defective or disconnected)</li> </ul>
H16	Outdoor current transformer open circuit	-	-	<ul style="list-style-type: none"> <li>Outdoor PCB</li> <li>IPM (Power transistor) module</li> </ul>
H19	Indoor fan motor mechanism locked	7 occurrences continuously	-	<ul style="list-style-type: none"> <li>Indoor PCB</li> <li>Fan motor</li> </ul>
H23	Indoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	○	<ul style="list-style-type: none"> <li>Heat exchanger temperature sensor (defective or disconnected)</li> </ul>
H27	Outdoor air temperature sensor abnormality	Continue for 5 sec.	○	<ul style="list-style-type: none"> <li>Outdoor temperature sensor (defective or disconnected)</li> </ul>
H28	Outdoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	○	<ul style="list-style-type: none"> <li>Outdoor heat exchanger temperature sensor (defective or disconnected)</li> </ul>
H30	Discharge temperature sensor abnormality	Continue for 5 sec.		<ul style="list-style-type: none"> <li>Outdoor discharge temperature sensor (defective or disconnected)</li> </ul>
H33	Indoor / outdoor wrong connection	-	-	<ul style="list-style-type: none"> <li>Indoor / outdoor supply voltage</li> </ul>
H38	Indoor / outdoor mismatch (brand code)	-	-	-
H64	Outdoor high pressure sensor abnormality	Continue for 1 minutes	-	<ul style="list-style-type: none"> <li>High pressure sensor</li> <li>Lead wire and connector</li> </ul>
H97	Outdoor fan lock abnormality	2 occurrences within 30 minutes		<ul style="list-style-type: none"> <li>Outdoor fan motor locked</li> </ul>
H98	Indoor temperature rise abnormality	-	-	<ul style="list-style-type: none"> <li>Air filter dirty</li> <li>Air circulation short circuit</li> </ul>
H99	Indoor heat exchanger freeze prevention protection	-	-	<ul style="list-style-type: none"> <li>Insufficient refrigerant</li> <li>Air filter dirty</li> </ul>
F11	4 way valve switching failure *	4 occurrences within 30 minutes	-	<ul style="list-style-type: none"> <li>4-way valve</li> <li>v-coil</li> </ul>
F17	Indoor standby units freezing abnormality	3 times happen within 40 minutes	-	<ul style="list-style-type: none"> <li>Check indoor/outdoor connection wire and pipe</li> <li>Indoor heat exchanger sensor lead wire and connector</li> <li>Expansion valve lead wire and connector.</li> </ul>
F90	System and compressor microcomputer communication error(for S10*** only)	2 occurrences within 5 seconds	-	<ul style="list-style-type: none"> <li>Compressor</li> <li>Outdoor PCB</li> </ul>
F90	Power factor correction abnormality	4 occurrences within 20 minutes	-	<ul style="list-style-type: none"> <li>Outdoor PCB</li> </ul>
F91	Refrigerant cycle abnormal	2 occurrences within 20 minutes	-	<ul style="list-style-type: none"> <li>No refrigerant ( 3-way valve is closed)</li> </ul>
F93	Outdoor compressor abnormal revolution	4 occurrences within 20 minutes	-	<ul style="list-style-type: none"> <li>Outdoor compressor</li> </ul>
F95	Cooling high pressure protection	4 occurrences within 20 minutes	-	<ul style="list-style-type: none"> <li>Outdoor refrigerant circuit</li> </ul>
F96	Intelligent power transistor overheating protection	-	-	<ul style="list-style-type: none"> <li>Excess refrigerant</li> <li>Improper heat radiation</li> <li>IPM (Power transistor)</li> </ul>
F97	Compressor temperature rise protection control	4 times occurrence within 20 minutes	-	<ul style="list-style-type: none"> <li>Insufficient refrigerant</li> <li>Compressor</li> </ul>
F98	Total running current protection	3 times occurrence within 20 minutes	-	<ul style="list-style-type: none"> <li>Excess refrigerant</li> <li>Improper heat radiation</li> </ul>
F99	Outdoor direct current (DC) peak detection	7 times occurrence continuously	-	<ul style="list-style-type: none"> <li>Outdoor PCB</li> <li>IPM (Power transistor)</li> <li>Compressor</li> </ul>

Note:

“○” – Frequency measured and fan speed fixed

“ \* ” – For cooling only model, it is the indication when indoor heat exchanger sensor or indoor air intake sensor has abnormality.

The memory data of error code is erased when the power supply is cut off, or press the Auto Switch until “beep” sound heard following by pressing the CHECK button at remote control.

Although operation forced to stop when abnormality detected, emergency operation is possible for certain errors (refer to Error Code Table) by using remote control or Auto OFF/ON button at indoor unit. However, the remote control signal receiving sound is changed from one “beep” to four “beep” sounds.



## 14.4 Troubleshooting Flowchart

### 14.4.1 H11 (Indoor/Outdoor Abnormal Communication)


#### Malfunction Decision Conditions

- During startup and operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

#### Malfunction Caused

- Faulty indoor unit PCB.
- Faulty outdoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wrong wiring.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- Indoor unit-outdoor unit signal transmission error due to disturbed power supply waveform.

#### Troubleshooting



## 14.4.2 H12 (Indoor/Outdoor Capacity Rank Mismatched)


### Malfunction Decision Conditions

- During startup, error code appears when different types of indoor and outdoor units are interconnected.

### Malfunction Caused

- Wrong models interconnected.
- Wrong indoor unit or outdoor unit PCBs mounted.
- Indoor unit or outdoor unit PCBs defective.
- Indoor-outdoor unit signal transmission error due to wrong wiring.
- Indoor-outdoor unit signal transmission error due to breaking of wire 3 in the connection wires between the indoor and outdoor units.

### Troubleshooting



### 14.4.3 H14 (Indoor Intake Air Temperature Sensor Abnormality)



#### Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the indoor intake air temperature sensor are used to determine sensor errors.

#### Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

#### Troubleshooting



#### 14.4.4 H15 (Compressor Temperature Sensor Abnormality)



##### Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor compressor temperature sensor are used to determine sensor errors.

##### Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

##### Troubleshooting



### 14.4.5 H16 (Outdoor Current Transformer Open Circuit)


#### Malfunction Decision Conditions

- A current transformer (CT) is detected by checking the compressor running frequency ( $\geq$  rated frequency) and CT detected input current (less than 1.14A) for continuously 20 seconds.

#### Malfunction Caused

- CT defective
- Outdoor PCB defective
- Compressor defective (low compression)

#### Troubleshooting



## 14.4.6 H19 (Indoor Fan Motor – DC Motor Mechanism Locked)


### Malfunction Decision Conditions

- The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550rpm or < 50rpm)

### Malfunction Caused

- Operation stops due to short circuit inside the fan motor winding.
- Operation stops due to breaking of wire inside the fan motor.
- Operation stops due to breaking of fan motor lead wires.
- Operation stops due to Hall IC malfunction.
- Operation error due to faulty indoor unit PCB.

### Troubleshooting



### 14.4.7 H23 (Indoor Pipe Temperature Sensor Abnormality)


#### Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the indoor heat exchanger temperature sensor are used to determine sensor errors.

#### Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

#### Troubleshooting



## 14.4.8 H27 (Outdoor Air Temperature Sensor Abnormality)



### Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor errors.

### Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

### Troubleshooting





## 14.4.9 H28 (Outdoor Pipe Temperature Sensor Abnormality)



### Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor errors.

### Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

### Troubleshooting



## 14.4.10 H30 (Compressor Discharge Temperature Sensor Abnormality)


### Malfunction Decision Conditions

- During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor errors.

### Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

### Troubleshooting



### 14.4.11 H33 (Unspecified Voltage between Indoor and Outdoor)


#### Malfunction Decision Conditions

- The supply power is detected for its requirement by the indoor/outdoor transmission.

#### Malfunction Caused

- Wrong models interconnected.
- Wrong indoor unit and outdoor unit PCBs used.
- Indoor unit or outdoor unit PCB defective.

#### Troubleshooting



## 14.4.12 H97 (Outdoor Fan Motor – DC Motor Mechanism Locked)


### Malfunction Decision Conditions

- The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor.

### Malfunction Caused

- Operation stops due to short circuit inside the fan motor winding.
- Operation stops due to breaking of wire inside the fan motor.
- Operation stops due to breaking of fan motor lead wires.
- Operation stops due to Hall IC malfunction.
- Operation error due to faulty outdoor unit PCB.

### Troubleshooting



### 14.4.13 H98 (Indoor High Pressure Protection)

Error Code will not display (no Timer LED blinking) but store in EEPROM


#### Malfunction Decision Conditions

- During heating operation, the temperature detected by the indoor pipe temperature sensor is above 140°F.

#### Malfunction Caused

- Clogged air filter of the indoor unit
- Dust accumulation on the indoor unit heat exchanger
- Air short circuit
- Detection error due to faulty indoor pipe temperature sensor
- Detection error due to faulty indoor unit PCB

#### Troubleshooting



#### 14.4.14 H99 (Indoor Freeze Prevention Protection: Cooling or Soft Dry)


##### Malfunction Decision Conditions

- Freeze prevention control takes place (when indoor pipe temperature is lower than 35.6°F)

##### Malfunction Caused

- Clogged air filter of the indoor unit
- Dust accumulation on the indoor unit heat exchanger
- Air short circuit
- Detection error due to faulty indoor pipe temperature sensor
- Detection error due to faulty indoor unit PCB

##### Troubleshooting



### 14.4.15 F11 (Indoor Pipe Temperature Sensor Abnormality)



#### Malfunction Decision Conditions

- When cooling operation, when indoor pipe temperature or indoor heat exchanger temperature sensor is above 113°F.

#### Malfunction Caused

- Faulty connector connection.
- Faulty indoor pipe temperature sensor.
- Faulty indoor main PCB.

#### Troubleshooting



## 14.4.16 F90 (Power Factor Correction Protection)


### Malfunction Decision Conditions

- During startup and operation of cooling and heating, when Power Factor Correction (PFC) protection circuitry at the outdoor unit main PCB senses abnormal high DC voltage level.

### Malfunction Caused

- DC voltage peak due to power supply surge.
- DC voltage peak due to compressor windings not uniform.
- Faulty outdoor PCB.

### Troubleshooting





### 14.4.17 F91 (Refrigeration Cycle Abnormality)


#### Malfunction Decision Conditions

- During cooling, compressor frequency =  $F_{\text{max}}$ .
- During cooling and heating operation, running current:  $0.65\text{A} < I < 1.65\text{A}$ .
- During cooling, indoor intake - indoor pipe  $< 39.2^{\circ}\text{F}$ .

#### Malfunction Caused

- Refrigerant shortage (refrigerant leakage)
- Poor compression performance of compressor.
- 2/3 way valve closed.
- Detection error due to faulty indoor intake air or indoor pipe temperature sensors.

#### Troubleshooting



14.4.18 F93 (Compressor Rotation Failure)


Malfunction Decision Conditions

A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused

- Compressor terminal disconnect
- Outdoor PCB malfunction

Troubleshooting



### 14.4.19 F95 (Cooling High Pressure Abnormality)


#### Malfunction Decision Conditions

During operation of cooling, when outdoor unit heat exchanger high temperature data (141.8°F) is detected by the outdoor pipe temperature sensor.

#### Malfunction Caused

- Outdoor pipe temperature rise due to short circuit of hot discharge air flow.
- Outdoor pipe temperature rise due to defective of outdoor fan motor.
- Outdoor pipe temperature rise due to defective outdoor pipe temperature sensor.
- Outdoor pipe temperature rise due to defective outdoor unit PCB.

#### Troubleshooting



14.4.20 F96 (IPM Overheating)


Malfunction Decision Conditions

During operating of cooling and heating, when IPM temperature data (212°F) is detected by the IPM temperature sensor.

Malfunction Caused

- IPM overheats due to short circuit of hot discharge air flow.
- IPM overheats due to defective of outdoor fan motor.
- IPM overheats due to defective of internal circuitry of IPM.
- IPM overheats due to defective IPM temperature sensor.

Troubleshooting



### 14.4.21 F97 (Compressor Overheating)


#### Malfunction Decision Conditions

During operation of cooling and heating, when compressor tank temperature data (233.6°F) is detected by the compressor tank temperature sensor.

#### Malfunction Caused

- Refrigerant shortage (refrigerant leakage).
- 2/3 way valve closed.
- Detection error due to faulty compressor tank temperature sensor.

#### Troubleshooting



## 14.4.22 F98 (Input Over Current Detection)


### Malfunction Decision Conditions

During cooling and heating operation, when an input over-current (16.8A) is detected by checking the input current value being detected by current transformer (CT) with the compressor running.

### Malfunction Caused

- Over-current due to compressor failure.
- Over-current due to defective outdoor unit PCB.
- Over-current due to defective inverter main circuit electrolytic capacitor.
- Over-current due to excessive refrigerant.

### Troubleshooting



### 14.4.23 F99 (Output Over Current Detection)


#### Malfunction Decision Conditions

During operation of cooling and heating, when an output over-current (18.5A) is detected by checking the current that flows in the inverter DC peak sensing circuitry.

#### Malfunction Caused

- DC peak due to compressor failure.
- DC peak due to defective power transistor(s).
- DC peak due to defective outdoor unit PCB.

#### Troubleshooting



- Checking the power transistor
- Never touch any live parts for at least 10 minutes after turning off the circuit breaker.
- If unavoidable necessary to touch a live part, make sure the power transistor's supply voltage is below 50V using the tester.
- For the UVW, make measurement at the Faston terminal on the board of the relay connector.

Tester's negative terminal	Power transistor (+)	UVW	Power transistor (-)	UVW
Tester's positive terminal	UVW	Power transistor (+)	UVW	Power transistor (-)
Normal resistance	Several kΩ to several MΩ			
Abnormal resistance	0 or ∞			

## 15. Disassembly and Assembly Instructions



### WARNING

High Voltage is generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.

### 15.1 Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures

#### 15.1.1 To remove front grille




Figure 1

#### 15.1.1.1 To remove power electronic controller




Figure 2






Figure 3




Figure 4




Figure 5

11. Detach the AC303 and CN-PCFM connectors from the electronic controller. Then pull out power electronic controller gently.

### 15.1.1.2 To remove discharge grille




Figure 6

### 15.1.1.3 To remove control board




Figure 7

### 15.1.1.4 To remove cross flow fan and indoor fan motor




Figure 8




Figure 9




Figure 10





Figure 11

16. Technical Data


16.1 Operation Characteristics

16.1.1 CS-S9NKUW-1 CU-S9NKU-1

- Cooling Characteristic
  - Room temperature: 81°F (DBT), 66°F (WBT)
  - Operation condition: High fan speed
  - Piping length: 24.6ft
  - Compressor Freq: Fc




- Piping Length Characteristic
  - Room temperature: 81°F (DBT), 66°F (WBT)
  - Operation condition: High fan speed
  - Outdoor temperature: 95°F (DBT)
  - Compressor Freq: Fc




16.1.2 CS-S12NKUW-1 CU-S12NKU-1

- Cooling Characteristic
  - Room temperature: 81°F (DBT), 66°F (WBT)
  - Operation condition: High fan speed
  - Piping length: 24.6ft
  - Compressor Freq: Fc




- Piping Length Characteristic
  - Room temperature: 81°F (DBT), 66°F (WBT)
  - Operation condition: High fan speed
  - Outdoor temperature: 95°F (DBT)
  - Compressor Freq: Fc




16.1.3 CS-S18NKU-1 CU-S18NKU-1

- Cooling Characteristic
  - Room temperature: 81°F (DBT), 66°F (WBT)
  - Operation condition: High fan speed
  - Piping length: 16.4ft
  - Compressor Freq: Fc






- Piping Length Characteristic
  - Room temperature: 81°F (DBT), 66°F (WBT)
  - Operation condition: High fan speed
  - Outdoor temperature: 95°F (DBT)
  - Compressor Freq: Fc




16.1.4 CS-S22NKU-1 CU-S22NKU-1

- Cooling Characteristic
  - Room temperature: 81°F (DBT), 66°F (WBT)
  - Operation condition: High fan speed
  - Piping length: 16.4ft
  - Compressor Freq: Fc




- Piping Length Characteristic
  - Room temperature: 81°F (DBT), 66°F (WBT)
  - Operation condition: High fan speed
  - Outdoor temperature: 95°F (DBT)
  - Compressor Freq: Fc



## 17. Exploded View and Replacement Parts List

### 17.1 Indoor Unit

#### 17.1.1 CS-S9NКУW-1 CS-S12NКУW-1



#### Note


The above exploded view is for the purpose of parts disassembly and replacement.  
The non-numbered parts are not kept as standard service parts.

REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-S9NKUW-1	CS-S12NKUW-1	REMARK
1	CHASSIS COMPLETE	1	CWD50C1633	←	
2	FAN MOTOR	1	L6CBYYL0055	←	O
3	CROSS-FLOW FAN COMPLETE	1	CWH02C1076	←	
4	BEARING ASSY	1	CWH64K007	←	
5	SCREW - CROSS-FLOW FAN	1	CWH551146	←	
7	EVAPORATOR	1	CWB30C3181	CWB30C3182	
8	FLARE NUT (LIQUID)	1	CWT251030	←	
9	FLARE NUT (GAS)	1	CWT251031	CWT251032	
10	CLIP FOR SENSOR	1	CWH32143	←	
12	CONTROL BOARD CASING	1	CWH102370A	←	
13	TERMINAL BOARD COMPLETE	1	CWA28C2357	←	O
14	ELECTRONIC CONTROLLER - MAIN	1	CWA73C6135	CWA73C6136	O
15	ELECTRONIC CONTROLLER - POWER	1	CWA745811	←	O
17	ELECTRONIC CONTROLLER - INDICATOR	1	CWA745740	←	O
19	SENSOR COMPLETE	1	CWA50C2135	←	O
20	CONTROL BOARD TOP COVER	1	CWH131350	←	
21	INDICATOR HOLDER	1	CWD933021	←	
22	CONTROL BOARD FRONT COVER CO.	1	CWH13C1201	←	
23	DISCHARGE GRILLE COMPLETE	1	CWE20C3038	←	
24	BACK COVER CHASSIS	1	CWD933233B	←	
25	FULCRUM	1	CWH621102	←	
26	VERTICAL VANE	11	CWE241287	←	
27	CONNECTING BAR	1	CWE261152	←	
28	CONNECTING BAR	1	CWE261154	←	
29	CONNECTING BAR	1	CWE261155	←	
30	CONNECTING BAR	1	CWE261153	←	
31	AIR SWING MOTOR	1	CWA981240	←	O
33	CAP - DRAIN TRAY	1	CWH521096	←	
34	HORIZONTAL VANE COMPLETE	1	CWE24C1268	←	
35	REMOTE CONTROL COMPLETE	1	CWA75C3580	←	O
36	FRONT GRILLE COMPLETE	1	CWE11C4512	←	O
37	INTAKE GRILLE COMPLETE	1	CWE22C1507	←	O
38	GRILLE DOOR COMPLETE	1	CWE14C1029	←	
39	AIR FILTER	2	CWD001279	←	
40	SCREW - FRONT GRILLE	2	XTT4+16CFJ	←	
41	CAP - FRONT GRILLE	2	CWH521194	←	
42	DRAIN HOSE	1	CWH851173	←	
43	INSTALLATION PLATE	1	CWH361097	←	
44	BAG COMPLETE - INSTALLATION SCREW	1	CWH82C1705	←	
45	OPERATING INSTRUCTION	1	CWF568314	←	
46	INSTALLATION INSTRUCTION	1	CWF615165	←	
48	AIR PURIFYING FILTER	1	CWD00C1141	←	
49	WIRE NET	1	CWD041144A	←	
50	BAG	1	CWG861497	←	
51	SHOCK ABSORBER (L)	1	CWG712940	←	
52	SHOCK ABSORBER (R)	1	CWG712941	←	
53	C.C.CASE	1	CWG565009	←	

(Note)

- All parts are supplied from PHAAM, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.

## 17.1.2 CS-S18NKU-1 CS-S22NKU-1



### Note

The above exploded view is for the purpose of parts disassembly and replacement.  
The non-numbered parts are not kept as standard service parts.


REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-S18NKU-1	CS-S22NKU-1	REMARK
1	CHASSIS COMPLETE	1	CWD50C1637	←	
2	FAN MOTOR	1	L6CBYYL0056	←	O
3	CROSS-FLOW FAN COMPLETE	1	CWH02C1077	←	
4	BEARING ASSY	1	CWH64K007	←	
5	SCREW - CROSS-FLOW FAN	1	CWH551146	←	
7	EVAPORATOR	1	CWB30C3771	CWB30C3772	
8	FLARE NUT (LIQUID)	1	CWT251030	←	
9	FLARE NUT (GAS)	1	CWT251032	CWT251033	
11	CLIP FOR SENSOR	1	CWH32143	←	
12	CONTROL BOARD CASING	1	CWH102370A	←	
13	TERMINAL BOARD COMPLETE	1	CWA28C2357	←	O
14	ELECTRONIC CONTROLLER - MAIN	1	CWA73C6143	CWA73C6144	O
15	ELECTRONIC CONTROLLER - POWER	1	CWA745811	←	O
17	ELECTRONIC CONTROLLER - INDICATOR	1	CWA745740	←	O
19	SENSOR COMPLETE	1	CWA50C2135	←	O
20	CONTROL BOARD TOP COVER	1	CWH131350	←	
21	INDICATOR HOLDER	1	CWD933021	←	
22	CONTROL BOARD FRONT COVER CO.	1	CWH13C1201	←	
23	DISCHARGE GRILLE COMPLETE	1	CWE20C3049	←	
24	FULCRUM	2	CWH621103	←	
25	VERTICAL VANE	15	CWE241289	←	
26	CONNECTING BAR	1	CWE261156	←	
27	CONNECTING BAR	1	CWE261158	←	
28	CONNECTING BAR	1	CWE261157	←	
29	CONNECTING BAR	1	CWE261159	←	
30	CONNECTING BAR	1	CWE261160	←	
31	AIR SWING MOTOR	1	CWA98K1014	←	O
32	AIR SWING MOTOR	1	CWA981241	←	O
34	CAP - DRAIN TRAY	1	CWH521096	←	
35	HORIZONTAL VANE COMPLETE	1	CWE24C1295	←	
36	BACK COVER CHASSIS	1	CWD933031B	←	
37	REMOTE CONTROL COMPLETE	1	CWA75C3582	←	O
38	FRONT GRILLE COMPLETE	1	CWE11C4514	←	O
39	INTAKE GRILLE COMPLETE	1	CWE22C1483	←	O
40	GRILLE DOOR COMPLETE	1	CWE14C1029	←	
41	AIR FILTER	2	CWD001283	←	
42	SCREW - FRONT GRILLE	3	XTT4+16CFJ	←	
43	CAP - FRONT GRILLE	3	CWH521194	←	
44	DRAIN HOSE	1	CWH851173	←	
45	INSTALLATION PLATE	1	CWH361098	←	
46	BAG COMPLETE - INSTALLATION SCREW	1	CWH82C1705	←	
47	OPERATING INSTRUCTION	1	CWF568314	←	
48	INSTALLATION INSTRUCTION	1	CWF615166	←	
49	WIRE NET	1	CWD041145A	←	
50	AIR PURIFYING FILTER	1	CWD00C1141	←	
51	BAG	1	CWG861498	←	
52	SHOCK ABSORBER (L)	1	CWG713033	←	
53	SHOCK ABSORBER (R)	1	CWG713034	←	
54	C.C.CASE	1	CWG565069	←	

(Note)

- All parts are supplied from PHAAM, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.

## 17.2 Outdoor Unit

### 17.2.1 CU-S9NKU-1 CU-S12NKU-1



#### Note

The above exploded view is for the purpose of parts disassembly and replacement.  
The non-numbered parts are not kept as standard service parts.




REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-S9NKU-1	CU-S12NKU-1	REMARK
1	CHASSIS ASSY	1	CWD50K2206A	←	
2	FAN MOTOR BRACKET	1	CWD541030	←	
3	SCREW - FAN MOTOR BRACKET	2	CWH551217	←	
4	FAN MOTOR	1	CWA951466	←	O
5	SCREW - FAN MOTOR MOUNT	4	CWH55406J	←	
6	PROPELLER FAN ASSY	1	CWH03K1010	←	
7	NUT - PROPELLER FAN	1	CWH56053J	←	
8	COMPRESSOR	1	5RS102XBC01	←	O
9	ANTI - VIBRATION BUSHING	3	CWH50077	←	
10	NUT - COMPRESSOR MOUNT	3	CWH56000J	←	
11	CONDENSER	1	CWB32C3010	←	
12	TUBE ASSY CO. (CAP./CHK VALVE)	1	CWT01C4383	CWT01C4384	
13	DISCHARGE MUFFLER (EXP VALVE)	1	CWB121010	←	
14	HOLDER COUPLING	1	CWH351015A	←	
15	2-WAYS VALVE (LIQUID)	1	CWB021301	←	O
16	3-WAY VALVE (GAS)	1	CWB011374	CWB011367	O
17	TERMINAL COVER	1	CWH171039A	←	
18	NUT - TERMINAL COVER	1	CWH7080300J	←	
19	SOUND PROOF BOARD	1	CWH151172A	←	
20	SOUND PROOF MATERIAL	1	CWG302314	←	
21	SOUND PROOF MATERIAL	1	CWG302563	←	
21A	SOUND PROOF MATERIAL	1	CWG302315	←	
21B	SOUND PROOF MATERIAL	1	CWG302316	←	
22	SENSOR CO-COMP TEMP	1	CWA50C2340	←	O
23	CONTROL BOARD COVER - TOP	1	CWH131264	←	
24	ELECTRONIC CONTROLLER - MAIN	1	CWA73C6151R	CWA73C6152R	O
26	TERMINAL BOARD ASSY	1	CWA28K1154	←	O
27	CABINET SIDE PLATE CO.	1	CWE04C1226	←	
28	SENSOR CO-AIR TEMP AND PIPE TEMP	1	CWA50C2670	←	O
29	CABINET SIDE PLATE (L)	1	CWE041492A	←	
30	CABINET FRONT PLATE CO.	1	CWE06C1142	←	
31	CABINET TOP PLATE	1	CWE031018A	←	
32	PLATE - C. B. COVER TERMINAL	1	CWH131301	←	
33	CONTROL BOARD COVER CO.	1	CWH13C1208	←	
36	REACTOR	1	CWA421050	G0A193M00001	
37	4-WAYS VALVE	1	CWB001058	←	
38	WIRE NET	1	CWD041111A	←	
39	BAG	1	CWG861078	←	
40	BASE BOARD - COMPLETE	1	CWG50C2388	←	
41	SHOCK ABSORBER (RIGHT)	1	CWG712209	←	
42	SHOCK ABSORBER (LEFT)	1	CWG712210	←	
43	C.C.CASE	1	CWG565107	←	

(Note)

- All parts are supplied from PHAAM, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.

## 17.2.2 CU-S18NKU-1 CU-S22NKU-1



### Note

The above exploded view is for the purpose of parts disassembly and replacement.  
The non-numbered parts are not kept as standard service parts.

REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-S18NKU-1	CU-S22NKU-1	REMARK
1	CHASSIS ASSY	1	CWD52K1227A	←	
2	ANTI - VIBRATION BUSHING	3	CWH50077	←	
3	COMPRESSOR	1	5CS130XAD04	←	O
4	NUT - COMPRESSOR MOUNT	3	CWH56000J	←	
5	FAN MOTOR BRACKET	1	CWD541126	←	
6	FAN MOTOR	1	CWA951686	←	O
7	SCREW - FAN MOTOR BRACKET	2	CWH551217	←	
8	SCREW - FAN MOTOR MOUNT	3	CWH551040J	←	
9	PROPELLER FAN ASSY	1	CWH001019	←	
10	NUT - PROPELLER FAN	1	CWH561038J	←	
11	CONDENSER	1	CWB32C2864	CWB32C2865	
12	EXPANSION VALVE	1	CWB051016J	←	
13	RECEIVER	1	CWB141053	-	
14	4-WAYS VALVE	1	CWB001057	←	
15	STRAINER	1	CWB111061	←	
16	HOLDER COUPLING	1	CWH351056A	←	
17	3-WAY VALVE (GAS)	1	CWB011338	CWB011623	O
18	2-WAYS VALVE (LIQUID)	1	CWB021292	←	O
19	SOUND PROOF BOARD	1	CWH151225	←	
20	TERMINAL COVER	1	CWH171039A	←	
21	NUT - TERMINAL COVER	1	CWH7080300J	←	
22	V-COIL COMPLETE	1	CWA43C2393	←	
23	SENSOR CO - COMP TEMP	1	CWA50C2689	←	O
24	SENSOR CO - AIR TEMP AND PIPE TEMP	1	CWA50C2710	←	O
25	REACTOR	1	G0C153J00007	←	O
26	CONTROL BOARD COVER-TOP	1	CWH131333	←	
27	TERMINAL BOARD ASSY	1	CWA28K1154	←	O
28	ELECTRONIC CONTROLLER - MAIN	1	CWA73C6155R	CWA73C6156R	O
29	CONTROL BOARD COVER - COMPLETE	1	CWH13C1210	←	
30	CABINET SIDE PLATE	1	CWE041489A	CWE041490A	
31	HANDLE	1	CWE161010	←	
32	CABINET SIDE PLATE CO.	1	CWE041487A	←	
33	CABINET FRONT PLATE CO.	1	CWE06K1069	←	
34	WIRE NET	1	CWD041128A	←	
35	CABINET TOP PLATE	1	CWE031131A	←	
36	CAPACITOR	1	DS441305NPQA	DS441355NPQA	O
37	ACCUMULATOR	1	CWB131024	←	
38	SOUND PROOF MATERIAL	1	CWG302302	CWG302270	
39	SOUND PROOF MATERIAL	1	CWG302513	CWG302300	
40	SOUND PROOF MATERIAL	1	CWG302503	-	
41	PLATE - C. B. COVER TERMINAL	1	CWH131332	←	
42	BAG	1	CWG861154	←	
43	BASE BOARD - COMPLETE	1	CWG62C1082	←	
44	SHOCK ABSORBER (RIGHT)	1	CWG712879	←	
45	SHOCK ABSORBER (LEFT)	1	CWG712880	←	
46	C.C.CASE	1	CWG565614	←	

(Note)

- All parts are supplied from PHAAM, Malaysia (Vendor Code: 00029488).
- “O” marked parts are recommended to be kept in stock.